

Personal Ultrasonic Jewelry Cleaner SparkleSpa Pro[®]




GEMORO[®]
The Sparkle Experts

Instructions for Use & Safety Precautions

FOR INDOOR USE ONLY

IMPORTANT: Before using the SparkleSpa Pro, please be certain to read the following pages including the specified safety precautions.

ADVANCED PROFESSIONAL FEATURES:

- True professional grade ultrasonic jewelry cleaner for the home
- Approximate 25oz (750ml) tank capacity
- Powerful 42,000Hz energy producing sound waves per second
- Digital timer
- Auto shut-off function
- 5 Cleaning cycles 90, 180, 280, 380 and 480 seconds
- Safely cleans most jewelry using tap water or for best results, add GemOro SparklePak Plus cleaning solution to the water (Item #0935 sold separately)
- Bright blue LED illuminated stainless steel tank
- Auto-opening transparent evaporation-free cover
- Quiet solid-state circuitry
- Elegant black European contoured design with chrome accents
- Removable basket and bracelet / watch holder included
- 50 / 60HZ
- One Year Limited Replacement Warranty



GemOro SparkleSpa Pro

1. Ultrasonic tank
2. Clear plastic evaporation resistant cover
3. Control panel: On/Off Button and Timer button
4. Blue LED light
5. Removable basket
6. Bracelet / watch holder

THE FIVE BASIC STEPS:

STEP 1 – Unpack the SparkleSpa Pro, basket and bracelet / watch holder from its box and plastic wrapping.

STEP 2 – Connect to electrical power source. DO NOT turn the ultrasonic on unless you have first filled up the tank with water.

STEP 3 – STEP 3 – To open the SparkleSpa Pro transparent cover, press the crescent shaped gray button that is located above the LED digital display to automatically expose the tank and add the appropriate amount of water and /or mixture of water and optional SparklePak Plus to the tank. Fill the solution level to the MAX fill line as clearly marked on the rear center portion of the stainless steel tank wall. DO NOT allow the water to evaporate below this level or fill the tank above this level as damage may occur and the warranty will become void. Depending on the item being cleaned, while we believe our GemOro SparklePak Plus cleaning solution with special brighteners and cleaning agents is the best ultrasonic jewelry cleaning solution available, water may also be mixed with alternative appropriate cleaning solutions (certain liquid household soaps, etc.) to also achieve better results. As an example, a small amount of dishwashing soap with a degreasing agent mixed with water will do the job. DO NOT use flammable liquids, ammonia or acid / water mixtures in

the ultrasonic tank as damage may occur and the warranty will become void. Keep the evaporation-free cover closed when not in use to reduce solution evaporation.

STEP 4 – BEFORE CLEANING JEWELRY READ SECTION “What May & May Not Be Cleaned In An Ultrasonic”.

Place the item to be cleaned in the supplied basket and then submerge it in the tank and close the cover. (As a suggestion, in the event small items such as diamond ear studs, charms or small pieces of jewelry require cleaning, a household stainless steel tea strainer or fine mesh stainless steel basket may be used to hold these items safely during the cleaning process, with the tea strainer then being placed in the supplied basket.) GemOro® Diamond Saver Basket (sold separately Item #5702) is recommended. To clean bracelets or metal watchbands, use the included holder that is designed for this function, while placing the holder in the basket to prevent it from touching the bottom of the tank. **DO NOT** place items to be cleaned directly on the tank bottom as damage to the transducer may occur. Damage to the transducer as a result of placing items on the bottom of the tank will void the warranty. Dents and scars on the tank’s bottom are evidence of items being placed inappropriately in the tank without a basket.

STEP 5 – Press the POWER button to start the cleaning process. While on, press the TIMER button to scroll through the five cleaning cycle times of 90, 180, 280, 380 or 480

seconds. Once the cleaning cycle has ended the ultrasonic will automatically shut off. Items that require additional cleaning may be left in the basket within the tank and the process repeated. Once the cleaning process has been completed, always rinse the item off with water to remove the remaining solution (as it may irritate your skin) and to dislodge / remove any remaining loosened dirt from its surface. DO NOT place fingers or other body parts in the tank while the ultrasonic is operating.

IMPORTANT: READ THIS SECTION BEFORE CLEANING JEWELRY

WHAT MAY & MAY NOT BE CLEANED IN AN ULTRASONIC

- Typically, items such as gold, silver, platinum, diamonds, rubies, sapphires, amethyst, citrine etc., are safe for ultrasonic cleaning. Be careful not to clean stones that may have many inclusions (example: emeralds), because the ultrasonic waves, heat or sudden change in temperature may crack the stone. Be certain not to clean soft, water porous stones (such as pearls, opals, turquoise, amber, ivory etc.) as they too may be damaged. For more specific information on which stones are suitable for cleaning in an ultrasonic, we suggest you contact a professional jeweler, gemologist or The Gemological Institute of America (GIA). Do not

submerge watches in an ultrasonic, as damage to the watch may occur. To clean metal watchbands, use the included holder which is designed for this function, while placing the holder in the basket to prevent it from touching the bottom of the tank. Watches should be placed on the holder with the head / movement of the watch suspended above the water in the tank to prevent potential damage due to a possible poor water seal or gasket in the watch. Never place a non-waterproof watch in water or in this ultrasonic and only place the metal band of the watch in the water. At your own risk, before attempting this, always be certain the watches stem is fully inserted and / or screwed all of the way in.

- Clean the tank and change the solution regularly, but ONLY after first unplugging the SparkleSpa Pro to avoid potential electrocution.
- With the SparkleSpa Pro unplugged, take the basket out of the tank and then grasp the ultrasonic with both hands and with the cover open, carefully pour out the old solution into your sink and drain. Wash all dirt and residue from the tank's bottom with clean water and a standard household non-ammoniated, non-acidic cleaning solution or stainless steel cleaner and a paper towel. Rinse the tank out with clean water while being careful not to allow water to overflow onto other parts of the machine as damage to its electronics may result and the warranty will become void.

- The SparkleSpa Pro's outer shell may also be cleaned using a standard household non-ammoniated, non-acidic, non-abrasive cleaning solution and a paper towel. After cleaning the outer shell, wipe off the remaining solution with clean water. Avoid placing too much cleaning solution on the outer shell as the excess solution may seep into the ultrasonic's electronics potentially causing damage. DO NOT submerge the SparkleSpa Pro into water as damage to its electronics may result and the warranty will become void.

PRELIMINARY GUIDELINE FOR GEMSTONE CLEANING

GEMSTONE	TOUGHNESS	ULTRASONIC
Alexandrite	excellent	usually
Amazonite	poor	never
Amber	poor	never
Amethyst	good	usually
Aquamarine	good	usually
Citrine	good	usually
Coral	fair	risky
Diamond	good	usually
Emerald	poor	never
Garnet	fair	usually
Iolite	fair	risky
Lapis Lazuli	fair	risky
Opal	fair	never
Pearl	good	never
Peridot	fair	risky
Ruby	excellent	usually
Sapphire	excellent	usually
Spinel	good	usually
Tanzanite	fair	never
Topaz	poor	never
Tourmaline	fair	risky
Turquoise	fair	never
Variscite	fair	never
Zircon	fair	risky

WARRANTY

Congratulations on your purchase of the prestige series, GemOro® SparkleSpa Pro personal ultrasonic jewelry cleaner! In the unlikely event of a defect in material or workmanship of the unit, your ultrasonic features a ONE YEAR LIMITED REPLACEMENT WARRANTY. This warranty is valid from the date of its purchase assuming the purchaser fills out the WARRANTY REGISTRATION FORM at www.gemoroproducts.com/warrantyregistration within 30 days of its purchase. If this criterion is not followed, the SparkleSpa Pro will automatically be covered by a 90 DAY LIMITED WARRANTY from the date your ultrasonic was purchased, as noted on the bill of sale (if supplied) or through the SparkleSpa Pro serial number tracking system as interpreted by the factory. In the event the SparkleSpa Pro is no longer available or has been discontinued and warranty coverage is applicable, at the factory's sole discretion, an equivalent ultrasonic cleaner may be substituted in place of the defective SparkleSpa Pro. The purchaser shall incur the cost for return postage, insurance and handling for all warranty and non-warranty repairs. Warranty repairs and/or replacements will be shipped back to the customer FOB Destination to the location of the customer's choosing if within the Continental United States (U.S.). Non-warranty repairs will be shipped back to the customer FOB Factory. Should the customer require the repair and/or replacement unit(s) to be shipped outside the Continental U.S., the customer will be required to pay any related shipping charges and any related taxes/duties for the respective destination country, regardless whether it is a warranty or non-warranty claim.

IMPORTANT DISCLAIMER: No warranties exist with respect to the SparkleSpa Pro or its use other than those expressly contained herein. All other warranties of any kind or character whatsoever, whether expressed or implied, including warranties of merchantability or fitness for a particular purpose, are hereby disclaimed and are excluded from the warranties hereunder. In the event that a claim is made with respect to the SparkleSpa Pro or its use, the maximum liability of GemOro, and its affiliates, dealers and distributors shall be the amount paid for the SparkleSpa Pro.

GemOro BrilliantSpa®

BLACK DIAMOND Deluxe Personal Jewelry Steam Cleaner

New larger capacity steamer with even greater steam pressure!

Cleans more & cleans faster – The best just got better!

- Professionally cleans diamonds, gold, silver and platinum jewelry
- Perfect size approximate 1-pint tank capacity steam cleaner
- Powerful steam cleaner safely generates a robust 50PSI of pressurized steam
- Using regular tap water safely blasts away dirt, grime, body oil, makeup and more
- Advanced LED indicator lights show when unit is heating and when it is ready to steam
- Bright blue LED light illuminates jewelry while being steam cleaned
- Features an unrestricted cleaning zone, removable cleaning / drying basket and convenient on / off power switch
- Includes jewelry holding tweezers, basket, steam residue mat and water funnel with measuring fill cup
- Complements sister product: GemOro Sparkle Spa Pro® Personal Ultrasonic Jewelry Cleaner
- Built for safety – ETL Listed
- 2 Year limited replacement warranty

Item #0375



GemOro UltraSpa™

THE ULTIMATE DUAL-ACTION JEWELRY CLEANER!

The world's only personal combination jewelry steam cleaner with built-in ultrasonic cleaner designed specifically for the home, *yet powerful enough for jewelers.*

- Perfect size approximate 1-pint tank capacity ultrasonic cleaner
- Ultrasonic generates a powerful 42,000 scrubbing waves per second using regular tap water
- Ultrasonic cleaner comes with a basket and evaporation resistant transparent cover, with bright blue built-in LED tank illumination
- Control panel provides a 6-minute timed ultrasonic cleaning cycle that automatically shuts off when completed
- Perfect size approximate 1-pint tank capacity steam cleaner
- Powerful steam cleaner safely generates a robust 50PSI of pressurized steam using regular tap water
- Easy to use steam control activation on demand for burst steam cleaning
- Built-in water fill funnel
- Includes: Steam residue mat, protective coated jewelry holding tweezers and handheld small mesh baskets for holding diamond ear studs, charms, etc. and measuring fill cup
- Designed in the USA for safety – ETL Listed
- 1 Year limited replacement warranty

Item #0377



GemOro SparklePak® Plus

Fill your ultrasonic tank with water, then take a convenient SparklePak Plus® and empty the contents in the water – Simple! *No measuring. No mixing. No mess. No waste.*



Amazing, professional strength, specially formulated jewelry cleaning solution. Each SparklePak Plus® contains the precise amount of our concentrated formula that when added to a full tank of water produces the best jewelry cleaning solution that will make your jewels sparkle like new!

Recommended for removing dirt, body oil, grime, cosmetics from jewelry and more! Non-ammoniated, non-toxic and non-flammable.

SparklePak Plus® For Consumer 1 to 1.5 Pint Ultrasonic or Sonic Cleaner
Box of 10 Ship wt. 1 lb Item #0937

12" Plastic Coated Stainless Steel Tweezers
Item #4703



Diamond Saver Basket
Item #5702





Gemoro Plus
Single Uses Ultrasonic Jewelry Cleaner
for up to 15 Pcs Ultrasonic
Some of your Best Looking

GEMORO
PRO PRODUCTS
The Gemoro Experts

Ultrasonic jewelry cleaning is the most effective way to clean your jewelry. Gemoro's ultrasonic jewelry cleaner uses high frequency sound waves to clean your jewelry. It's safe for all types of jewelry. Gemoro's ultrasonic jewelry cleaner is the only one that's safe for all types of jewelry. Gemoro's ultrasonic jewelry cleaner is the only one that's safe for all types of jewelry.

On/Off

7:00

Timer

GEMORO
SPARKLESPA PRO



10455 Olympic Drive, Dallas, Texas 75220 USA

Tel 800.527.0719 or 214.351.0380

Fax 800.832.9871 or 214.351.1903

www.sparkleexperts.com

www.gemoroproducts.com

sales@sparkleexperts.com

support@sparkleexperts.com